

FLUFFO FRAME

non-flammable, large-format
acoustic panels

DIRECTIONS FOR USE



Do not apply excessive pressure to the fabric surface. The fabric is resistant to temporary pressure and quickly returns to its original tension. However, prolonged pressure may cause permanent deformation of the stretched fabric surface.



The panels are vulnerable to mechanical damage. Be careful not to damage the panels with sharp objects, backrests, edges or corners of furniture. Leaning against the panels is not advisable.



The panels should be mounted away from open flames, sparks and other heat sources such as electric heaters.



Avoid staining the decorative fabric.



The panels should be installed out of reach of pets.

ATTENTION! Cats may use the panel's surface as a scratcher causing snags in the fabric.

CLEANING AND CARE INSTRUCTIONS



Dust will settle on the panels just as it does on any other furniture. In order to remove dust from aluminium surfaces, use a soft-bristled dusting brush or a soft, dry cloth. To remove dust from fabric, use a soft-bristled brush or a vacuum cleaner with a standard brush for upholstered furniture.



In order to remove lightweight, superficial stains from the fabric, use a soft cloth slightly dampened with clean water. More stubborn stains should be removed with a soft sponge dampened with diluted detergent. Wipe the entire surface of the fabric to avoid leaving cleaning marks in one spot. In extreme cases, if the stain is still visible despite cleaning, the fabric can be replaced with a new one (in this case, please contact us).



Avoid rubbing the fabric surface vigorously with a wet sponge and using strong detergents, such as bleach or washing powder.



In order to clean the aluminium frame, use a soft, slightly damp cloth. For more persistent stains, you can use a soft sponge with water and a mild, pH-neutral detergent (pH 6–8). After the cleaning, wipe the frame with a clean, damp cloth, then dry it thoroughly with a soft, dry cloth.



Do not use cleaning products containing chlorine, strong acids or highly alkaline substances (e.g. ammonia, caustic soda) to clean the aluminium frame, as these may damage the anodised finish. Also avoid cleaning agents based on organic solvents, as these can cause discolouration. Do not use abrasive materials such as steel wool, rough sponges, scouring powders. These may leave permanent scratches on the frame's surface.

The above information is based on our best knowledge, and serves only as a guideline. We are always happy to provide information and technical advice regarding our products. We reserve the right to make changes in our offer at any time. It is up to the customer to make sure that our panels' technical characteristics fit the purpose set by the customer. We will not take responsibility for the consequences resulting from non-compliance with our recommendations.
